



SA-VP1001RW *Home model*

Cordless multi-use handstick vacuum cleaner with nozzles for various surfaces

With the cordless upright vacuum cleaner, you can conveniently vacuum both hard floors and carpets. Thanks to its practical nozzles, you can remove dirt from hard-to-reach nooks and crannies, such as corners under the ceiling, window blinds or sofas.

- Nozzles **for different surfaces**
- **Up to 20 minutes*** of uninterrupted cleaning
- Even **60 m²**** on a single battery charge
- Convenient **adjustment of the telescopic tube** – 7 levels
- **Vertical parking position** - ergonomic construction
- **4-stage filtration** that traps dust, pollen and bacteria
- LED backlight



AnimalJet electro brush



Narrow XL crevice nozzle



2-in-1 brush



Wall mount

SHARP
Be Original.


sharphomeappliances.com

Meet the multifunctional Sharp **SA-VP1001RW** vacuum cleaner




Vertical parking position

The vacuum cleaner does not need a stand and will remain upright wherever you leave it. You don't need to bend down to grab it every time you want to take a break from cleaning. The standing position also makes it easier to store the vacuum cleaner in a wardrobe or a closet. If you prefer, you can hang the device on a special wall-mounted holder.



Adjustable telescopic tube

You can easily adjust the length of the tube to your height and set it at one of the seven levels of adjustment from 890 to 1100 mm. You can also set the length of the tube to thoroughly clean all hard-to-reach places. Vacuuming corners under the ceiling has never been as easy and convenient!



Set of nozzles

The two nozzles in the set will make it easier to clean hard-to-reach places such as any corners or elements of upholstered furniture. The flexible bristle of the 2-in-1 nozzle easily and efficiently removes dust and dirt.



Long working time

When fully charged, the lithium-ion battery allows for 20* minutes of uninterrupted vacuuming, which means that you can quickly clean an apartment with a surface of up to 60 m²**. The battery can be easily removed and replaced with a spare one (sold separately on the service) when you plan a bigger clean-up.



Lithium-ion battery

The high-quality lithium-ion battery (24V max) can be easily removed and replaced with a spare one (sold separately on the website). It takes 3.5 hours for the battery to fully charge.



AnimalJet electro brush with LED light

It has been designed to collect animal hair, hair and dust from floors, carpets, along walls and furniture edges. Thanks to the LED lighting, you won't miss anything, while the appropriate profiling of the brush protects furniture, walls and thresholds from damage.



4-stage filtration

Not only does it protect the motor from dust particles, but it also keeps pollen, mite faeces and bacteria inside the dust container. The EPA E12 filter captures 99.5% of harmful particles. When necessary, you can wash it under running water or replace it with a new one.



Hygienic emptying of the container

Press the button to open the dust container and empty it directly into the dustbin.

Easy cleaning of different types of surfaces

Conveniently and thoroughly clean the entire apartment using accessories for various surfaces.



Included in the set



Wall mount

The vacuum cleaner, although smart and neat, does not need to be visible. It can be mounted on a wall bracket and stored away, so that it does not take up space and you can keep everything in order.



AnimalJet electro brush

It is intended for cleaning both hard floors and carpets. Select the appropriate program (carpet or floor) to remove all dust, crumbs and pet hair. The special design of the brush will make it easier to clean the surface along the walls and furniture. Thanks to LED lighting, you can see dust even in shaded places, e.g. under furniture.



Narrow XL crevice nozzle

Dust and crumbs tend to gather in crevices behind furniture or in car seats. To get rid of them quickly, use the narrow crevice nozzle XL to remove dirt in hard-to-reach places.



2-in-1 brush

With the 2-in-1 nozzle, you can quickly remove dust that gathers on delicate elements, such as blinds. A soft brush will adapt to the surface to be cleaned and remove dirt without causing any damage.

*When using nozzles without their own motor. Actual operating time may vary depending on the type of flooring and/or accessories used.

**When working on a hard floor. The actual vacuuming surface may vary depending on the type of floor and/or accessories used.

***Handheld vacuum cleaner with a telescopic tube and the AnimalJet electric brush.



Cordless multi-use handstick vacuum cleaner **SA-VP1001RW**

KEY FEATURES

Model	SA-VP1001RW
Color	white and red
Operating mode	Eco
Operating time [min.]	up to 20*
Cleaning surface [m²]	up to 60**
Filter	EPA E12, washable and replaceable
Battery type	Lithium-ion, removable
Battery level indicator	yes, LED
Battery charging time [h]	3.5
Type of motor	DC
Max voltage [V]	24
Noise level	<82 db
Dust container capacity [l]	0.65
Storage	wall mount included
EAN UE code	4974019150604
EAN UK code	4974019150598

DIMENSIONS AND WEIGHT

Product dimensions (H x W x D) [mm]	1100x250x170
Package dimensions (H x W x D) [mm]	800x305x155
Product net weight*** [kg]	2.54
Gross weight with packaging [kg]	4.8

ACCESSORIES

Basic	Telescopic tube, wall mount, XL crevice nozzle, 2-in-1 nozzle, AnimalJet electric brush, power supply, 21.6V battery (24V max)
-------	---